



All installations should be done by a certified electrician



Installation Instructions



Before connecting and powering the lamp, please ensure that:

- 1. All Power is off.
- 2. The led light is connected to the driver. Marry the male and female pins (b&c) as shown above.
- 3. The driver is connected to AC 100-240V. Connect point A to ac power $(100^{\sim}240V)$ and ensure the connection is secure.
- ${\bf 4.} \ \ In stall \ \ the \ \ lamp \ as shown in the installation \ drawing.$
- 5. Check the entire circuit and ensure that all is perfect.

Warnings!

To avoid the risk of electric shock, do not attempt to open the power supply.

In order to avoid the risk of fire , use only the power supply included in the kit with LED panels